

0325013 POLISHED CHROME PUSH TO OPEN DOUBLE BUTTON ((12CM X 12)

SKU: 0325013



Categories: [Electrical and Switchgear](#), [Individual Switches](#)



0325013 Polished Chrome Push To Open Double Button ((12cm x 12)